

Basics / Getting Started

(Controls = car icon on bottom left of screen)

Action	How-To
Unlock Car	Tap key card against driver's side pillar just below the camera.
Lock Car (from outside)	Tap key card against driver's side pillar just below the camera.
Start Car	Place key card on center console behind cup holders. Press brake pedal.
Put into Drive	While pressing brake pedal, push right drive stalk all the way down.
Put into Park	While pressing brake pedal, press button on end of right drive stalk.
Put into Reverse	While pressing brake pedal, push right drive stalk all the way up.
Adjust Steering Wheel	Controls -> Quick Controls -> Adjustments -> Steering Wheel. Use left control button on steering wheel.
Adjust Mirrors	Controls -> Quick Controls -> Adjustments -> Mirrors. Use left control button on steering wheel.
Open Door (from outside)	Press thumb against wide part of the handle and grab the part that comes out with your fingers and pull.
Open Door (from inside)	Press the button near the upper tip of the arm rest and push the door open.
Turn on Wipers	Press button on end of left turn signal stalk. Adjust wiper speed on screen. (set to auto)
Turn on Headlights	Control -> Lights. (set to auto)
Flash Highbeams	Pull left turn signal stalk towards you.
Hazard lights	Press button in ceiling.
Wash Windshield	Hold down button on end of left turn signal

	stalk.
Parking Break	Once in park, hold down button on end of right drive stalk.
Open Trunk	Controls -> Quick Controls -> Open
Close Trunk	Press switch on underside of trunk handle
Open Front Trunk / Hood ("Frunk")	Controls (car icon on bottom left of screen) -> Quick Controls -> Open
Close Frunk	Press down with both hands on either side of the latch. Slowly press until latch catches. Gently pull to verify closed.

Recommended Settings

Setting	How-To
Walk-away door locks enabled	Controls -> Locks -> Walk-Away Door Lock = On
Lock confirmation sound enabled	Controls -> Locks -> Lock Confirmation Sound = On
Set Stopping Mode to HOLD	Controls -> Driving -> Stopping Mode = HOLD
Enable Autosteer	Controls -> Autopilot -> Autosteer = On